

PC



MODEL(ΦD-T)											
Tube(Metric)-Thread(R)			Tube(Inch)-Thread(R)			Tube(Inch)-Thread(NPT)			Tube(Metric)-Thread(G)		
PC 04-M5	PC 06-04	PC 12-02	PC 1/4-01	PC 1/2-02	PC 5/32-U	PC 1/4-N2	PC 3/8-N4	PC 04-G01	PC 10-G01		
PC 04-M6	PC 08-01	PC 12-03	PC 1/4-02	PC 1/2-03	PC 5/32-N1	PC 1/4-N3	PC 1/2-N1	PC 04-G02	PC 10-G02		
PC 04-01	PC 08-02	PC 12-04	PC 1/4-03	PC 1/2-04	PC 5/32-N2	PC 1/4-N4	PC 1/2-N2	PC 04-G03	PC 10-G03		
PC 04-02	PC 08-03	PC 16-03	PC 5/16-01		PC 5/32-N3	PC 5/16-N1	PC 1/2-N3	PC 06-G01	PC 10-G04		
PC 04-03	PC 08-04	PC 16-04	PC 5/16-02		PC 3/16-U	PC 5/16-N2	PC 1/2-N4	PC 06-G02	PC 12-G02		
PC 06-M5	PC 10-01		PC 5/16-03		PC 3/16-N1	PC 5/16-N3		PC 06-G03	PC 12-G03		
PC 06-M6	PC 10-02		PC 3/8-01		PC 3/16-N2	PC 5/16-N4		PC 08-G01	PC 12-G04		
PC 06-01	PC 10-03		PC 3/8-02		PC 3/16-N3	PC 3/8-N1		PC 08-G02	PC 16-G03		
PC 06-02	PC 10-04		PC 3/8-03		PC 1/4-U	PC 3/8-N2		PC 08-G03	PC 16-G04		
PC 06-03	PC 12-01		PC 3/8-04		PC 1/4-N1	PC 3/8-N3		PC 08-G04			

PC-G



PCF



MODEL(ΦD-T)											
Tube(Metric)-Thread(Rc)			Tube(Inch)-Thread(Rc)			Tube(Inch)-Thread(NPT)			Tube(Metric)-Thread(G)		
PCF 04-M5	PCF 08-01	PCF 12-03	PCF 1/4-01			PCF 5/32-N1	PCF 5/16-N3	PCF 04-G01	PCF 08-G04		
PCF 04-01	PCF 08-02	PCF 12-04	PCF 1/4-02			PCF 5/32-N2	PCF 5/16-N4	PCF 04-G02	PCF 10-G01		
PCF 04-02	PCF 08-03		PCF 5/16-01			PCF 3/16-N1	PCF 3/8-N1	PCF 04-G03	PCF 10-G02		
PCF 04-03	PCF 08-04		PCF 5/16-02			PCF 3/16-N2	PCF 3/8-N2	PCF 06-G01	PCF 10-G03		
PCF 06-M5	PCF 10-01		PCF 3/8-02			PCF 1/4-N1	PCF 3/8-N3	PCF 06-G02	PCF 10-G04		
PCF 06-01	PCF 10-02		PCF 3/8-03			PCF 1/4-N2	PCF 3/8-N4	PCF 06-G03	PCF 12-G02		
PCF 06-02	PCF 10-03					PCF 1/4-N3	PCF 1/2-N2	PCF 08-G01	PCF 12-G03		
PCF 06-03	PCF 10-04					PCF 5/16-N1	PCF 1/2-N3	PCF 08-G02	PCF 12-G04		
PCF 06-04	PCF 12-02					PCF 5/16-N2		PCF 08-G03			

PCF-G



POC



MODEL(ΦD-T)											
Tube(Metric)-Thread(R)			Tube(Inch)-Thread(R)			Tube(Inch)-Thread(NPT)					
POC 04-M5	POC 06-03	POC 12-01	POC1/4-01			POC5/32-U	POC5/16-N1	POC1/2-N4			
POC 04-M6	POC 08-01	POC 12-02	POC1/4-02			POC5/32-N1	POC5/16-N2				
POC 04-01	POC 08-02	POC 12-03	POC5/16-01			POC5/32-N2	POC5/16-N3				
POC 04-02	POC 08-03	POC 12-04	POC5/16-02			POC3/16-U	POC3/8-N1				
POC 04-03	POC 08-04		POC3/8-02			POC3/16-N1	POC3/8-N2				
POC 06-M5	POC 10-01		POC3/8-03			POC3/16-N2	POC3/8-N3				
POC 06-M6	POC 10-02					POC1/4-U	POC3/8-N4				
POC 06-01	POC 10-03					POC1/4-N1	POC1/2-N2				
POC 06-02	POC 10-04					POC1/4-N2	POC1/2-N3				

PMM



MODEL(ΦD)	
Tube(Metric)	Tube(Inch)
PMM 04	PMM 5/32
PMM 06	PMM 3/16
PMM 08	PMM 1/4
PMM 10	PMM 5/16
PMM 12	PMM 3/8
	PMM 1/2

PCP



MODEL(ΦD)	
Tube(Metric)	Tube(Inch)
PCP 04	PCP 5/32
PCP 06	PCP 3/16
PCP 08	PCP 1/4
PCP 10	PCP 5/16
PCP 12	PCP 3/8
PCP 16	PCP 1/2

PMF



MODEL(ΦD-T)											
Tube(Metric)-Thread(Rc)			Tube(Inch)-Thread(NPT)			Tube(Metric)-Thread(G)					
PMF 04-01	PMF 08-04	PMF 5/32-N1	PMF 3/8-N3	PMF04-G01	PMF10-G02						
PMF 04-02	PMF 10-01	PMF 3/16-N1	PMF 1/2-N2	PMF04-G02	PMF10-G03						
PMF 04-03	PMF 10-02	PMF 3/16-N2	PMF 1/2-N3	PMF04-G03	PMF10-G04						
PMF 06-01	PMF 10-03	PMF 1/4-N1	PMF 1/2-N4	PMF06-G01	PMF12-G02						
PMF 06-02	PMF 10-04	PMF 1/4-N2		PMF06-G02	PMF12-G03						
PMF 06-03	PMF 12-02	PMF 5/16-N1		PMF06-G03	PMF12-G04						
PMF 08-01	PMF 12-03	PMF 5/16-N2		PMF08-G01							
PMF 08-02	PMF 12-04	PMF 5/16-N3		PMF08-G02							
PMF 08-03		PMF 3/8-N2		PMF08-G03							

PMF-G



PL



Swivel Rotating Type

MODEL(ΦD-T)											
Tube(Metric)-Thread(R)			Tube(Inch)-Thread(R)			Tube(Inch)-Thread(NPT)			Tube(Metric)-Thread(G)		
PL04-M5	PL06-04	PL12-02	PL1/4-01	PL1/2-02	PL-5/32-U	PL-1/4-N3	PL-1/2-N3	PL04-G01	PL10-G01		
PL04-M6	PL08-01	PL12-03	PL1/4-02	PL1/2-03	PL-5/32-N1	PL-5/16-N1	PL-1/2-N4	PL04-G02	PL10-G02		
PL04-01	PL08-02	PL12-04	PL1/4-03	PL1/2-04	PL-5/32-N2	PL-5/16-N2		PL04-G03	PL10-G03		
PL04-02	PL08-03	PL16-03	PL5/16-01		PL-3/16-U	PL-5/16-N3		PL06-G01	PL10-G04		
PL04-03	PL08-04	PL16-04	PL5/16-02		PL-3/16-N1	PL-5/16-N4		PL06-G02	PL12-G02		
PL06-M5	PL10-01		PL5/16-03		PL-3/16-N2	PL-3/8-N1		PL06-G03	PL12-G03		
PL06-M6	PL10-02		PL3/8-01		PL-3/16-N3	PL-3/8-N2		PL08-G01	PL12-G04		
PL06-01	PL10-03		PL3/8-02		PL-1/4-U	PL-3/8-N3		PL08-G02	PL16-G03		
PL06-02	PL10-04		PL3/8-03		PL-1/4-N1	PL-3/8-N4		PL08-G03	PL16-G04		
PL06-03	PL12-01		PL3/8-04		PL-1/4-N2	PL-1/2-N2		PL08-G04			

PL-G



PLF



Swivel Rotating Type

MODEL(ΦD-T)											
Tube(Metric)-Thread(Rc)			Tube(Inch)-Thread(NPT)			Tube(Metric)-Thread(G)					
PLF 04-M5	PLF 08-02		PLF-5/32-U	PLF-5/16-N2		PLF 04-G01	PLF 10-G03				
PLF 04-M6	PLF 08-03		PLF-5/32-N1	PLF-5/16-N3		PLF 04-G02	PLF 10-G04				
PLF 04-01	PLF 08-04		PLF-5/32-N2	PLF-3/8-N2		PLF 06-G01	PLF 12-G02				
PLF 04-02	PLF 10-01		PLF-3/16-U	PLF-3/8-N3		PLF 06-G02	PLF 12-G03				
PLF 06-M5	PLF 10-02		PLF-3/16-N1	PLF-3/8-N4		PLF 06-G03	PLF 12-G04				
PLF 06-M6	PLF 10-03		PLF-3/16-N2	PLF-1/2-N3		PLF 08-G01					
PLF 06-01	PLF 10-04		PLF-1/4-U	PLF-1/2-N4		PLF 08-G02					
PLF 06-02	PLF 12-02		PLF-1/4-N1			PLF 08-G03					
PLF 06-03	PLF 12-03		PLF-1/4-N2			PLF 08-G04					
PLF 06-04	PLF 12-04		PLF-1/4-N3			PLF 10-G01					
PLF 08-01			PLF-5/16-N1			PLF 10-G02					

PLF-G



Swivel Rotating Type

PLL



Swivel Rotating Type

MODEL(ΦD-T)											
Tube(Metric)-Thread(R)			Tube(Inch)-Thread(R)			Tube(Inch)-Thread(NPT)			Tube(Metric)-Thread(G)		
PLL 04-M5	PLL 06-04	PLL 12-02	PLL1/4-01			PLL-5/32-U	PLL-1/4-N3	PLL04-G01	PLL08-G04		
PLL 04-M6	PLL 08-01	PLL 12-03	PLL1/4-02			PLL-5/32-N1	PLL-5/16-N1	PLL04-G02	PLL10-G01		
PLL 04-01	PLL 08-02	PLL 12-04	PLL5/16-01			PLL-5/32-N2	PLL-5/16-N2	PLL04-G03	PLL10-G02		
PLL 04-02	PLL 08-03		PLL5/16-02			PLL-3/16-U	PLL-5/16-N3	PLL06-G01	PLL10-G03		
PLL 04-03	PLL 08-04		PLL3/8-02			PLL-3/16-N1	PLL-3/8-N2	PLL06-G02	PLL10-G04		
PLL 06-M5	PLL 10-01		PLL3/8-03			PLL-3/16-N2	PLL-3/8-N3	PLL06-G03	PLL12-G02		
PLL 06-M6	PLL 10-02					PLL-3/16-N3	PLL-3/8-N4	PLL08-G01	PLL12-G03		
PLL 06-01	PLL 10-03					PLL-1/4-U	PLL-1/2-N2	PLL08-G02	PLL12-G04		
PLL 06-02	PLL 10-04					PLL-1/4-N1	PLL-1/2-N3	PLL08-G03			
PLL 06-03	PLL 12-01					PLL-1/4-N2	PLL-1/2-N4				

PLL-G



Swivel Rotating Type

PT



Swivel Rotating Type

MODEL(ΦD-T)											
Tube(Metric)-Thread(R)			Tube(Inch)-Thread(R)		Tube(Inch)-Thread(NPT)			Tube(Metric)-Thread(G)			
PT 04-M5	PT 06-04	PT 12-02	PT1/4-01	PT1/2-02	PT5/32-U	PT1/4-N3	PT1/2-N3	PT04-G01	PT10-G01		
PT 04-M6	PT 08-01	PT 12-03	PT1/4-02	PT1/2-03	PT5/32-N1	PT5/16-N1	PT1/2-N4	PT04-G02	PT10-G02		
PT 04-01	PT 08-02	PT 12-04	PT1/4-03	PT1/2-04	PT5/32-N2	PT5/16-N2		PT04-G03	PT10-G03		
PT 04-02	PT 08-03	PT 16-03	PT5/16-01		PT3/16-U	PT5/16-N3		PT06-001	PT10-G04		
PT 04-03	PT 08-04	PT 16-04	PT5/16-02		PT3/16-N1	PT5/16-N4		PT06-G02	PT12-G02		
PT 06-M5	PT 10-01		PT5/16-03		PT3/16-N2	PT3/8-N1		PT06-G03	PT12-G03		
PT 06-M6	PT 10-02		PT3/8-01		PT3/16-N3	PT3/8-N2		PT08-G01	PT12-G04		
PT 06-01	PT 10-03		PT3/8-02		PT1/4-U	PT3/8-N3		PT08-G02	PT16-G03		
PT 06-02	PT 10-04		PT3/8-03		PT1/4-N1	PT3/8-N4		PT08-G03	PT16-G04		
PT 06-03	PT 12-01		PT3/8-04		PT1/4-N2	PT1/2-N2		PT08-G04			

PTF



MODEL(ΦD-T)					
Tube(Metric)-Thread(Rc)		Tube(Inch)-Thread(NPT)		Tube(Metric)-Thread(G)	
PTF 04-M5	PTF 08-02	PTF5/32-U	PTF5/16-N1	PTF04-G01	PTF10-G02
PTF 04-M6	PTF 08-03	PTF5/32-N1	PTF5/16-N2	PTF04-G02	PTF10-G03
PTF 04-01	PTF 08-04	PTF5/32-N2	PTF5/16-N3	PTF06-G01	PTF10-G04
PTF 04-02	PTF 10-01	PTF3/16-U	PTF3/8-N2	PTF06-G02	PTF12-G02
PTF 06-M5	PTF 10-02	PTF3/16-N1	PTF3/8-N3	PTF06-G03	PTF12-G03
PTF 06-M6	PTF 10-03	PTF3/16-N2	PTF3/8-N4	PTF08-G01	PTF12-G04
PTF 06-01	PTF 10-04	PTF1/4-U	PTF1/2-N3	PTF08-G02	
PTF 06-02	PTF 12-02	PTF1/4-N1	PTF1/2-N4	PTF08-G03	
PTF 06-03	PTF 12-03	PTF1/4-N2		PTF08-G04	
PTF 08-01	PTF 12-04	PTF1/4-N3		PTF10-G01	

PTF-G



PST



MODEL(ΦD-T)					
Tube(Metric)-Thread(R)		Tube(Inch)-Thread(R)	Tube(Inch)-Thread(NPT)	Tube(Metric)-Thread(G)	
PST 04-M5	PST 08-02	PST1/4-01	PST5/32-U	PST5/16-N2	PST 04-G01
PST 04-M6	PST 08-03	PST1/4-02	PST5/32-N1	PST5/16-N3	PST 10-G03
PST 04-01	PST 08-04	PST1/4-03	PST5/32-N2	PST5/16-N4	PST 12-G02
PST 04-02	PST 10-01	PST5/16-01	PST3/16-U	PST3/8-N1	PST 06-G01
PST 04-03	PST 10-02	PST5/16-02	PST3/16-N1	PST3/8-N2	PST 12-G04
PST 06-M5	PST 10-03	PST5/16-03	PST3/16-N2	PST3/8-N3	PST 06-G03
PST 06-M6	PST 10-04	PST3/8-02	PST3/16-N3	PST3/8-N4	PST 08-G01
PST 06-01	PST 12-01	PST3/8-03	PST1/4-U	PST1/2-N2	PST 08-G02
PST 06-02	PST 12-02	PST3/8-04	PST1/4-N1	PST1/2-N3	PST 08-G03
PST 06-03	PST 12-03	PST1/2-02	PST1/4-N2	PST1/2-N4	PST 08-G04
PST 06-04	PST 12-04	PST1/2-03	PST1/4-N3		PST 10-G01
PST 08-01		PST1/2-04	PST5/16-N1		PST 10-G02

PST-G



PWT



MODEL(ΦD-T)					
Tube(Metric)-Thread(R)		Tube(Inch)-Thread(R)	Tube(Inch)-Thread(NPT)	Tube(Metric)-Thread(G)	
PWT 04-M5	PWT 08-02	PWT1/4-01	PWT5/32-U	PWT5/16-N2	PWT04-G01
PWT 04-M6	PWT 08-03	PWT1/4-02	PWT5/32-N1	PWT5/16-N3	PWT04-G02
PWT 04-01	PWT 08-04	PWT1/4-03	PWT5/32-N2	PWT5/16-N4	PWT04-G03
PWT 04-02	PWT 10-01	PWT5/16-01	PWT3/16-U	PWT3/8-N1	PWT06-G01
PWT 04-03	PWT 10-02	PWT5/16-02	PWT3/16-N1	PWT3/8-N2	PWT06-G02
PWT 06-M5	PWT 10-03	PWT5/16-03	PWT3/16-N2	PWT3/8-N3	PWT06-G03
PWT 06-M6	PWT 10-04	PWT3/8-02	PWT3/16-N3	PWT3/8-N4	PWT06-G04
PWT 06-01	PWT 12-01	PWT3/8-03	PWT1/4-U	PWT1/2-N2	PWT08-G01
PWT 06-02	PWT 12-02	PWT3/8-04	PWT1/4-N1	PWT1/2-N3	PWT08-G02
PWT 06-03	PWT 12-03	PWT1/2-02	PWT1/4-N2	PWT1/2-N4	PWT08-G03
PWT 06-04	PWT 12-04	PWT1/2-03	PWT1/4-N3		PWT08-G04
PWT 08-01		PWT1/2-04	PWT5/16-N1		PWT10-G01

PWT-G



PLM



MODEL(ΦD)	
Tube(Metric)	Tube(Inch)
PLM 04	PLM 5/32
PLM 06	PLM 3/16
PLM 08	PLM 1/4
PLM 10	PLM 5/16
PLM 12	PLM 3/8
	PLM 1/2

PXT




MODEL(ΦD-T)	
Tube(Metric)-Thread(R)	Tube(Metric)-Thread(G)
PXT 04-01	PXT 04-G01
PXT 04-02	PXT 04-G02
PXT 06-01	PXT 06-G01
PXT 06-02	PXT 06-G02

PKD



MODEL(ΦD1-ΦD2-T)		
Tube(Metric)	Tube(Inch)	Tube(Metric)-Thread(G)
PKD 0604-01	PKD 3/16-5/32-N1	PKD 0604-G01
PKD 0804-01	PKD 1/4-5/32-N1	PKD 0804-G01
PKD 0804-02	PKD 5/16-5/32-N2	PKD 0804-G02
PKD 0806-01	PKD 5/16-3/16-N2	PKD 0806-G01
PKD 0806-02	PKD 5/16-1/4-N2	PKD 0806-G02
PKD 1006-02	PKD 3/8-1/4-N3	PKD 1006-G02
PKD 1006-03	PKD 3/8-5/16-N3	PKD 1006-G03
PKD 1008-02		PKD 1008-G02
PKD 1008-03		PKD 1008-G03

PKD-G



CAS



MODEL(ΦD)	
Tube(Metric)	Tube(Inch)
CAS 04	CAS 5/32
CAS 06	CAS 3/16
CAS 08	CAS 1/4
CAS 10	CAS 5/16
CAS 12	CAS 3/8
	CAS 1/2

PH



MODEL(ΦD-T)					
Tube(Metric)-Thread(R)		Tube(Inch)-Thread(R)	Tube(Inch)-Thread(NPT)	Tube(Metric)-Thread(G)	
PH 03-M5	PH 08-01	PH1/4-M5	PH 1/8-U	PH 1/4-N3	PH 04-G01
PH 04-M6	PH 08-02	PH1/4-01	PH 5/32-U	PH 5/16-N1	PH 04-G02
PH 04-M5	PH 08-03	PH1/4-02	PH 5/32-N1	PH 5/16-N2	PH 06-G01
PH 04-01	PH 08-04	PH5/16-01	PH 5/32-N2	PH 5/16-N3	PH 06-G02
PH 04-02	PH 10-01	PH5/16-02	PH 3/16-U	PH 5/16-N4	PH 06-G03
PH 06-M5	PH 10-02	PH5/16-03	PH 3/16-N1	PH 3/8-N2	PH 08-G01
PH 06-M6	PH 10-03	PH3/8-02	PH 3/16-N2	PH 3/8-N3	PH 08-G02
PH 06-01	PH 10-04	PH3/8-03	PH 3/16-N3	PH 3/8-N4	PH 08-G03
PH 06-02	PH 12-02		PH 1/4-U	PH 1/2-N3	PH 08-G04
PH 06-03	PH 12-03		PH 1/4-N1	PH 1/2-N4	PH 10-G02
PH 06-04	PH 12-04		PH 1/4-N2		PH 10-G03

PH-G



PHF



MODEL(ΦD-T)					
Tube(Metric)-Thread(R)		Tube(Inch)-Thread(R)	Tube(Inch)-Thread(NPT)	Tube(Metric)-Thread(G)	
PHF 03-M5	PHF 08-01	PHF 1/4-M5	PHF 1/8-U	PHF 5/16-N1	PHF 04-G01
PHF 04-M5	PHF 08-02	PHF 1/4-01	PHF 5/32-U	PHF 5/16-N2	PHF 04-G02
PHF 04-M6	PHF 08-03	PHF 1/4-02	PHF 5/32-N1	PHF 5/16-N3	PHF 04-G03
PHF 04-01	PHF 08-04	PHF 5/16-01	PHF 3/16-U	PHF 5/16-N4	PHF 04-G04
PHF 04-02	PHF 10-01	PHF 5/16-02	PHF 3/16-N1	PHF 3/8-N2	PHF 06-G01
PHF 06-M5	PHF 10-02	PHF 5/16-03	PHF 3/16-N2	PHF 3/8-N3	PHF 06-G02
PHF 06-M6	PHF 10-03	PHF 3/8-02	PHF 3/16-N3	PHF 3/8-N4	PHF 06-G03
PHF 06-01	PHF 10-04	PHF 3/8-03	PHF 1/4-U	PHF1/2-N3	PHF 06-G04
PHF 06-02	PHF 12-02		PHF 1/4-N1	PHF1/2-N4	PHF 08-G01
PHF 06-03	PHF 12-03		PHF 1/4-N2		PHF 08-G02
PHF 06-04	PHF 12-04		PHF 1/4-N3		PHF 08-G03

PHF-G



PHL(2)



MODEL(ΦD-T)			
Tube(Metric)-Thread(R)		Tube(Metric)-Thread(G)	
PHL 04-01(2)	PHL 08-03(2)	PHL 04-G01(2)	PHL 08-G03(2)
PHL 04-02(2)	PHL 08-04(2)	PHL 04-G02(2)	PHL 08-G04(2)
PHL 04-03(2)	PHL 10-01(2)	PHL 04-G03(2)	PHL 10-G01(2)
PHL 04-04(2)	PHL 10-02(2)	PHL 04-G04(2)	PHL 10-G02(2)
PHL 06-01(2)	PHL 10-03(2)	PHL 06-G01(2)	PHL 10-G03(2)
PHL 06-02(2)	PHL 10-04(2)	PHL 06-G02(2)	PHL 10-G04(2)
PHL 06-03(2)	PHL 12-02(2)	PHL 06-G03(2)	PHL 12-G02(2)
PHL 06-04(2)	PHL 12-03(2)	PHL 06-G04(2)	PHL 12-G03(2)
PHL 08-01(2)	PHL 12-04(2)	PHL 08-G01(2)	PHL 12-G04(2)
PHL 08-02(2)		PHL 08-G02(2)	

PHL-G(2)



PHT(1)



MODEL (φD-T)			
Tube(Metric)-Thread(R)		Tube(Metric)-Thread(G)	
PHT 04-01(1)	PHT 08-03(1)	PHT 04-G01(1)	PHT 08-G03(1)
PHT 04-02(1)	PHT 08-04(1)	PHT 04-G02(1)	PHT 08-G04(1)
PHT 04-03(1)	PHT 10-01(1)	PHT 04-G03(1)	PHT 10-G01(1)
PHT 04-04(1)	PHT 10-02(1)	PHT 04-G04(1)	PHT 10-G02(1)
PHT 06-01(1)	PHT 10-03(1)	PHT 06-G01(1)	PHT 10-G03(1)
PHT 06-02(1)	PHT 10-04(1)	PHT 06-G02(1)	PHT 10-G04(1)
PHT 06-03(1)	PHT 12-02(1)	PHT 06-G03(1)	PHT 12-G02(1)
PHT 06-04(1)	PHT 12-03(1)	PHT 06-G04(1)	PHT 12-G03(1)
PHT 08-01(1)	PHT 12-04(1)	PHT 08-G01(1)	PHT 12-G04(1)
PHT 08-02(1)		PHT 08-G02(1)	

PHT-G(1)



PHT(2)



MODEL (φD-T)			
Tube(Metric)-Thread(R)		Tube(Metric)-Thread(G)	
PHT 04-01(2)	PHT08-03(2)	PHT 04-G01(2)	PHT 08-G03(2)
PHT 04-02(2)	PHT08-04(2)	PHT 04-G02(2)	PHT 08-G04(2)
PHT 04-03(2)	PHT10-01(2)	PHT 04-G03(2)	PHT 10-G01(2)
PHT 04-04(2)	PHT10-02(2)	PHT 04-G04(2)	PHT 10-G02(2)
PHT 06-01(2)	PHT10-03(2)	PHT 06-G01(2)	PHT 10-G03(2)
PHT 06-02(2)	PHT10-04(2)	PHT 06-G02(2)	PHT 10-G04(2)
PHT 06-03(2)	PHT12-02(2)	PHT 06-G03(2)	PHT 12-G02(2)
PHT 06-04(2)	PHT12-03(2)	PHT 06-G04(2)	PHT 12-G03(2)
PHT 08-01(2)	PHT12-04(2)	PHT 08-G01(2)	PHT 12-G04(2)
PHT 08-02(2)		PHT 08-G02(2)	

PHT-G(2)

